



**DF7670**

**Product Features:**

- 15.5-oz, 100% polyester fleece
- 5.4-oz, 100% DWR nylon panels at upper body, sleeves and hem
- Zippered hand pockets with polyester tricot lining
- Drawcord and toggles at hem

Adult sizes: XS-4XL



**Icons/Fabric Features:**



**Available Colours and PMS Colours**

Textile fabric colours are subject to dye lot variation and will not be exact match to print pantone reference

BLACK / BLACK



Black 6C / Black 6C

ASPHALT / BLACK



Between 431C & 432C / Black 6C

WARMTH RATING	MILD	● WARM	WARMER	WARMEST
WATER PROTECTION	● WATER RESISTANT PANELS		WATERPROOF	
WIND RESISTANT	YES			
WIND AND WATER PROTECTION	DWR PANELS			

Due to the nature of nylon, special care must be taken throughout the decoration process.

## DF7670 - DRYFRAME® Huron Jacket

### GARMENT MEASUREMENTS

Size	XS	S	M	L	XL	2XL	3XL	4XL
<b>Chest - Half Measure</b>	20 1/4"	21 3/4"	23 1/4"	24 3/4"	26 1/4"	27 3/4"	29 3/4"	31 3/4"
<b>Chest - Full Measure</b>	40 1/2"	43 1/2"	46 1/2"	49 1/2"	52 1/2"	55 1/2"	59 1/2"	63 1/2"
<b>Body Length from HPS (At Front)</b>	28"	28 1/2"	29"	29 1/2"	30 1/2"	31 1/2"	32"	32 1/2"
<b>Sleeve Length-CB</b>	34 3/4"	35 1/2"	36 1/4"	37"	37 3/4"	38 1/2"	39 1/4"	40"

*Finished measurements in inches. Refer to "How to Measure" guide for detailed information on measurement instructions.*

### ADULT General Sizing Guide

Size	XS	S	M	L	XL	2XL	3XL	4XL
<b>Chest</b>	30"-32"	34"-36"	38"-40"	42"-44"	46"-48"	50"-52"	54"-55"	56"-57"
<b>Waist</b>	26"-29"	29"-32"	32"-35"	35"-38"	38"-41"	41"-44"	44"-47"	47"-50"
<b>Sleeve Length-CB</b>	31"-32"	32"-33 1/2"	34"-35"	35"-36"	36"-37"	37"-38"	38"-39"	38 1/2"-39"



### PRINTING INSTRUCTIONS FOR NYLON FABRICS

**Due to the nature of Nylon fabric, special care must be taken throughout the decoration process. Special care must be taken during the decoration process and after.**

Here are some tips to effectively decorate these products.

#### Heat Transfer/Screen Printing:

- Garment temperature must not exceed 310°F or 154°C.
- Use fast fushion/low cure temperature ink to help prevent the need for a higher temperature to cure the ink.
- A test sample run is recommended in all printing processes, especially if you have a large order or if your printer does not specialize in printing on Nylon fabrics.